



EYEWASH INSPECTION RECORD

PI: _____ Building: _____ Room: _____

NOTE:

- Eyewash must be tested and inspected monthly.
- Post an Eyewash Inspection Record near each eyewash.
- **Outlet heads (lids covering where water flows from) should be kept closed when not in use**

Instructions:

- Run the eyewash for 2-3 minutes, ensuring:
 - there is sufficient water flow
 - the hands-free mechanism is functioning
- Initial the appropriate box below to document a passing inspection
- If inspection fails, notify all users and call Campus Services: 727-7463 for repairs

	Year: _____		Year: _____	
	Date of Inspection	Initials of Person Testing	Date of Inspection	Initials of Person Testing
January				
February				
March				
April				
May				
June				
July				
August				
September				
October				
November				
December				